

# Midea Commercial & VRF systems to KNX Application

The Midea Application has been specially designed to allow bidirectional control and monitoring of Midea Commercial & VRF systems from a KNX installation.

The solution allows the integration of up to 64 indoor units from a single Interface.

# FEATURES

UL Listed.

Direct access to outdoor unit's communication bus.

Scan: Automatic identification of the units presents on the VRF system.

Energy consumption signals from each indoor unit are available.


Supports KNX standard datapoints (DPTs) that guarantees a seamless integration with any KNX device or system.

Wide range of monitoring & control datapoints available.

Configuration through IP or USB (Console) port.

Easy integration with Intesis MAPS.

Automatic updates for both Intesis MAPS and interface's firmware.



# Description

# DIRECT CONNECTION TO VRF OUTDOOR UNITS

The gateway is directly connected to the outdoor unit's communication bus and enables the control of all the indoor units connected to the system. This allows not only the control and monitoring of the main AC functions but the access to some internal variables of the outdoor units.

# T UP BY INTESIS MAPS

- configuration is carried out using the Intesis MAPS software. This one allows you to define your own settings for the device and offers extra functions available for all the new generation gateways. Thanks to the scan function, which allows to automatically discover all the units available in



the installation, get the interface ready to work in a really short time. Intesis MAPS makes it easy to identify any malfunction in the installations thanks to its robust diagnostic feature.

### **Technical Documentation**

User Manual	General information about this product	Download
Installation Manual	Learn how to install the device in your project	Download
Application Wiring Diagram	Review your specific application wiring diagram	Download
HVAC Compatibility tool	Find the appropriate solution for your HVAC integration	Open
EC Declaration of Conformity	Check the product certification	Download
UKCA Certification	Check the product UKCA Certification	Download
Recommendations to avoid polarity issues	How to avoid polarity issues in RS485 Networks	Learn more

#### **Programming Tools**

Intesis MAPS	Get access to download the configuration software tool	Download
Intesis MAPS User Manual	General information about Intesis MAPS	Download
eLearning course	Learn the secrets of Intesis MAPS	Enroll now

# **Commercial Documentation**

Marketing Datasheet	Discover all the integration solutions for Midea	Download
Intesis Brochure	Know more about the Intesis current available products	Download

# **HVAC Compatibility**

Ensure the compatibility of this gateway with your AC model by visiting <u>https://compatibility.intesis.com/</u>

# Compatible AC models

MDV-D - Q1/N1-C | MDV-D - Q1/N1-D | MDV-D - Q1/N1 | MDV-D - Q2/N1 | MDV-D - Q4/N1-A3 | MDV-D - Q4/N1-D | MI - Q4/DHN1-A3 | MI -Q4/DHN1-D | MCA3I - FNXD0 | MCA3I - HRFN1-QRC8 | MCA3U - HRFN1-QRD0W | MCA3 - HRFN1-QRC8W(B) | MCD - FNXD0 | MCD - HRFN1-QRC8W(D) | MCD - HRFN1-QRD0 | MCA3 - HRFN1-QRD0 | MKD-V - F | MDV-D - T1/N1-B | MDV-D - T2/N1-DA5 | MDV-D - T3/N1-B | MDV-D -T3/N1-C | MDV-D - T2/N1-CA5 | MDV-D - T2/N1-BA5 | MVM - A-VA1 | MDV-D - T1/N1 | MI - T1/DHN1-B | MI - T2/DHN1-DA5 | MTBI - HWFN1-QRD0 | MTB - HWFN1-QRC8W(B) | MTB - HWFN1-QRC8W(D) | MTBU - QRD0W | MTBU - HWFN1-QRD0 | MTI - FNXD0 | MTI - HWFN1-QRD0 | MTIU - FNXD0 | MI - T2/DHN1-BA5 | AHUKZ - | AHUKZ - B | MDV-D - DL/N1-C | MI - DL/DHN1-C | MUE - FNXD0 | MUE - HRFN1-QRD0 | MI-D -Z/N1-F4 | MDV-D - Z/N1-F4 | MDV-D - Z/N1-F5 | MDV-D - Z/N1-F3B | MDV-D - G-R3/N1Y | MDV-D - G/DN1YB | MDV-D - G/N1YB | MDV-D -G/N1-S | MDV-D - G/DN1-S | MI - G/DHN1-M | MSMBAU - HRFN1-QRD0GW(B) | MSMBBU - HRFN1-QRD0GW(B) | MSMBCU - HRFN1-QRD0GW(B) | MSMBDU - HRFN1-QRD0GW(B) | MDV-D - Z/DN1-B | MFAI - HRFN1-QRC8 | MFAU - HRFN1-QRD0 | MFA - HRFN1-QRC8W | MDV-D - T1/N1-FA | MFM - HRFN1-QRD0 | MFM - ARFN1-RRD0 | MDV-V - W/DN1 (outdoor) | MDV-V - W/DN1(B) (outdoor) | MDV-V - W/DRN1 (outdoor) | MDV-V - W/DRN1(A) (outdoor) | MDV - W/DRN1-i(B) (outdoor) | MDV - W/DRN1-i(C) (outdoor) | MV5-E - W/V2GN1 (outdoor) | MV5-X - W/V2GN1 (outdoor) | MDVS - (8)W/DRN1 (outdoor) | MDVS - (10)W/DRN1 (outdoor) | MDVS - (12)W/DRN1 (outdoor) | MDV -(8)W/D2RN1T(C) (outdoor) | MDV - (10)W/D2RN1T(C) (outdoor) | MDV - (12)W/D2RN1T(C) (outdoor) | MDV - (14)W/D2RN1T(C) (outdoor) | V - (16)W/D2RN1T(C) (outdoor) | MV - (8)W/D2RN1T(D) (outdoor) | MV - (10)W/D2RN1T(D) (outdoor) | MV - (12)W/D2RN1T(D) (outdoor) V - (14)W/D2RN1T(D) (outdoor) | MV - (16)W/D2RN1T(D) (outdoor) | MSAGDU-xxHRFN8-QRD0GW (2) (outdoor) | MSAGCU-xxHRFNXvRD0GW (2) (outdoor) | MSAGBU-xxHRFN8-QRD1GW(GA) (2) (outdoor) | MSAGDU-xxHRFNX-QRD0GW (2) (outdoor) | MCA3I-xxHRFNX-QRD0

(outdoor) | MCA3U-xxHRFNX-QRD0W (outdoor) | MCD-xxHRFNX-QRD0 (outdoor) | MTIU-xxHWFNX-QRD0W(V1) (outdoor) | MTIU-xxHWFNX-QRD0W (outdoor) | MTI-xxHWFNX-QRD0(V1) (outdoor) | MTI-xxHWFNX-QRD0 (outdoor) | MUEU-xxHRFNX-QRD0W (outdoor) | MUE-xxHRFNX-QRD0 (outdoor) | MUEU-xxHRFNX-QRD0W (outdoor) | MUE-xxHRFNX-QRD0W (outdoor) | MUEU-xxHRFNX-QRD0W (outdooR)W | MUEU-xXHRFNX-QRDW (outdoOR) | MUEU-xXHRFNX-QRDW (outdoOR) | MUEU-xXHRFNX-QRDW (outdoOR) | MUEU-xXHRFNX-QRDW (ou

KAYSUN AC models

KCI - DMN8 | KCI - DN10 | KCI - DMNU9 | KFC-CI-2T - D | KFC-CI-4T - D | KCIS - DMNU9 | KCIS - DN10 | KFC-CIS-2T - D | KFC-CIS-4T - D | KCOF - DN2.4 | KCIF - DN3.0 | KCIBF - DN3.0 | KPD - DMN7 | KPD - DN10 | KPD - DMNU8 | KPDF - DN3.0 | KPDHF - DN3.0 | KPDHF - DN2.4 | KPC - DN10 | KPCF - DN3.0 | KSF - DN2.3 | KAYF - DN3.0 | KFC-AY-2T - D | KFC-AY-2T - | KSDF - DN2.3 | KSD - DMN6 | KSD - DN9 | KSD - DMNU8 | KPV - DN10

\* The asterisks stand for any character in the asterisk' position.

File	Version	Size	Read online	
ORDER CODES:				
IN770AIR00SO000	Intesis multi-brand AC interface with KNX, Serial and IP support - Up to 16 Indoor Units			
IN770AIR00MO000	Intesis multi-brand AC interface with KNX, S	Serial and IP support	- Up to 64 Indoor Units	

The order code can differ depending on the product seller and the buyer's location.

ightarrow For the older version, please click here to find the documentation

### INCLUDED COMPONENTS:

Intesis Gateway.

Installation Manual.

USB Configuration cable.

(Power supply not included).

Warranty: 36 months.

Copyright © 2020 HMS Industrial Networks - All rights reserved.